The New California Landscape

Maintaining Landscapes for Low Water Use

Loren Oki

Landscape Horticulture Specialist Dept. of Plant Sciences, UC Davis

Chico, CA September 10, 2015



University of **California** Agriculture and Natural Resources

Topics

- Why plants need water
- Irrigation management
 - Assessing system performance
 - Scheduling
 - Smart controllers
- Maintaining plants
 - Turf
 - Trees and shrubs
 - Edibles
- Fire Safe

Topics

• Why plants need water



Soil-Plant-Atmosphere continuum

Why do plants need water? How does water move from the soil, up a plant, and into the air?

The concept of water potential

Water moves down an energy gradient

Potential energy components of water in substrates

- Matric potential
- Gravimetric potential
- Solute potential



The concept of Lower water potential at Water leaf tips transpires as vapor Water moves down an energy gradient 0 Potential energy Water column -under tension components of water in substrates Matric potential Q Gravimetric potential Water Soil Solute potential 0 Higher water

roots

potential in



Plant Water Relations

CO₂ is necessary for photosynthesis Water is lost as CO₂ is taken into the leaves

Topics

- Why plants need water
- Irrigation management
 - Assessing system performance

The Need To Measure

"I often say that when you can measure what you are speaking about, and express it in numbers, you know something about it; but when you cannot express it in numbers, your knowledge is of a meager and unsatisfactory kind." *Lord Kelvin*

"If it can't be expressed in figures, it is not science; it is opinion." *Robert Heinlein*

Conducting An Irrigation Audit

1. Inspect the site

- a) Meter
- b) Main shut-off valve
- c) Controller
- d) Valves
- e) Zones
 - a) Drip: in-line, point-source, flow rates, micro spray
 - b) Overhead: fan, multi-stream rotor, gear drive rotor
 - c) Manufacturer & model, quantity
 - d) Site characteristics
- f) Pressure: static vs dynamic
- Credit: Irrigation Association Landscape Irrigation Auditor certification program

Conducting An Irrigation Audit

- 1. Inspect the site
- 2. Tune up the irrigation system
- 3. Test the system (collect data)
- 4. Calculate performance
- 5. Interpret the information

Credit: Irrigation Association Landscape Irrigation Auditor certification program

Conducting An Irrigation Audit

- Tune up the irrigation system
 - Repair, replace, update
- Rebates
 - Rotary stream sprinklers, drip systems, smart controllers, conversions
 - www.ccuh.ucdavis.edu/public/drought/map

Topics

- Why plants need water
- Irrigation management
 - Assessing system performance
 - Scheduling
 - 3 methods

- Things you need to know
 - Distribution uniformity
 - Precipitation rate
 - Soil texture
 - Landscape and plant coefficients (K_L)
 - Climate (ET₀)

- Things you need to know
 - Distribution uniformity
 - How evenly water is applied
 - Applies to overhead and drip
 - Catch can test





- Things you need to know
 - Distribution uniformity
 - Catch can test
 - Calculate average volume collected (Avg_T)
 - Sort the volumes
 - Calculate the average of the lowest ¼ (Avg_{LQ})
 - $DU = Avg_{LQ} \div Avg_{T}$
 - Should be AT LEAST 0.7
 - If less than 0.7, repairs or modifications are needed

- Things you need to know
 - Distribution uniformity
 - Precipitation rate

- Things you need to know
 - Distribution uniformity
 - Precipitation rate
 - How fast water is applied

$$PR = \frac{Avg_{T}}{C \times T} \times 3.66$$

 Avg_T = Average of all catch can volumes (mL)

- C = Throat area of catch can (sq. in.)
- T = Run time (min.)

- Things you need to know
 - Distribution uniformity
 - Precipitation rate
 - Soil texture
 - Plant available water

Soil Texture Affects Soil Moisture

Water Holding Capacity

Permeability



Sandy: Apply small amounts frequently Clay: Apply larger amounts slowly, less often

Soil Texture and Irrigation



Graphic: Brady & Weil, The Nature and Properties of Soils, 2002

12:30

Soil T	exture	Plant Avail Water
		(CIII/CIII)
Coarse	sand / fine sand	0.05
	loamy sand	0.07
Moderately Coarse	sandy loam	0.11
Medium	loam	0.16
	silty loam	0.2
	silt	0.2
Moderately Fine	sandy clay loam	0.15
	clay loam	0.16
	silty clay loam	0.18
Fine	sandy clay	0.12
	silty clay	0.14
	clay	0.15

*Irrigation Association Landscape Irrigation Auditor Manual page 177

Soil T	exture	Plant Avail Water (cm/cm)*	Irrig to Wet to Depth (in)**
Coarse	sand / fine sand	0.05	0.3
	loamy sand	0.07	0.42
Moderately Coarse	sandy loam	0.11	0.66
Medium	loam	0.16	0.96
	silty loam	0.2	1.2
	silt	0.2	1.2
Moderately Fine	sandy clay loam	0.15	0.9
	clay loam	0.16	0.96
	silty clay loam	0.18	1.08
Fine	sandy clay	0.12	0.72
	silty clay	0.14	0.84
	clay	0.15	0.9

*Irrigation Association Landscape Irrigation Auditor Manual page 177

Soil T	exture	Plant Avail Water (cm/cm)*	Irrig to Wet to Depth (in)**						
Coarse	sand / fine sand	0.05	0.3						
	loamy sand	0.07	0.42						
Moderately Coarse	sandy loam	0.11	0.66						
Medium	loam	0.16	0.96						
	silty loam	0.2	1.2	>					
	silt	0.2	1.2						
Irrig to wet to o	depth	= 12" ×	0.2 × 50% = 1	.2″					
Desired depth to	wet = 12"								
Plant avail water = 0.2, so 12" × 0.2= 2.4"									
Assume 50% dry down (1/2 of the water is used), then 1.2"									

*Irrigation Association Landscape Irrigation Auditor Manual page 177

Soil T	exture	Plant Avail Water (cm/cm)*	Irrig to Wet to Depth (in)**	Infiltration Rate (in/hr)
Coarse	sand / fine sand	0.05	0.3	1.5
	loamy sand	0.07	0.42	1
Moderately Coarse	sandy loam	0.11	0.66	0.8
Medium	loam	0.16	0.96	0.4
	silty loam	0.2	1.2	0.25
	silt	0.2	1.2	0.3
Moderately Fine	sandy clay loam	0.15	0.9	0.1
	clay loam	0.16	0.96	0.07
	silty clay loam	0.18	1.08	0.05
Fine	sandy clay	0.12	0.72	0.08
	silty clay	0.14	0.84	0.05
	clay	0.15	0.9	0.05

*Irrigation Association Landscape Irrigation Auditor Manual page 177

Run-time

		Plant Avail Water	Irrig to Wet to Depth	Infiltration Rate
	Soil Texture	(cm/cm)*	(in)**	(in/hr)
Medium	silty loam	0.2	1.2	0.25

- Calculating Run-time
 - Lower Boundary (LB)
 - PR = 1.35 in/hr
 - Irrigation to wet to depth = 1.2".

Run-time

- Calculating Run-time with DU
 - Upper Boundary (UB)
 - Scheduling multiplier (SM)
 - DU = 0.65
 - Lower boundary (LB) = 53 min.

- Things you know
 - Distribution uniformity
 - Precipitation rate
 - Soil texture

- Things you know
 - Distribution uniformity = 0.65
 - Precipitation rate
 - Soil texture
 - Lower boundary
 - Upper boundary

- = 1.35 in/hr
- = silty loam
- = 53 min
- = 67 min
- This is how much to water
- Now we need to know when to irrigate

- Things you need to know
 - Distribution uniformity
 - Precipitation rate
 - Soil texture
 - Landscape and plant coefficients (K_L)

Landscape Coefficients

Information on plant water use **WUCOLS**

www.ucanr.sites/WUCOLS

🖒 SHARE 🖂 EMAIL 🔒 PRINT 🗮 SITE MAP Enter Search Tern

WUCOLS IV Water Use Classification of Landscape Species

Home Page

GETTING STARTED

Home Page User Manual

Plant Search Instructions

Plant Search Database

Download WUCOLS IV Plant List

Download WUCOLS IV User Manual

Water Requirements for Turfgrasses

Partners

Acknowledgements

If you are using the WUCOLS list for the first time, it is essential that you read the User Manual. The manual contains very important information regarding the evaluation process, categories of water needs, plant types, and climatic regions. It is necessary to know this information to use WUCOLS evaluations and the plant search tool appropriately. To access the User Manual, click on the tab (on left) and view specific topics.

Water conservation is an essential consideration in the design and management of California landscapes. Effective strategies that increase water use efficiency must be identified and implemented. One key strategy to increase efficiency is matching water supply to plant needs. By supplying only the amount of water needed to maintain landscape health and appearance, unnecessary applications that exceed plant needs can be avoided. Doing so, however, requires some knowledge of plant water needs.

WUCOLS IV provides evaluations of the irrigation water needs for over 3,500 taxa (taxonomic plant groups) used in California landscapes. It is based on the observations and extensive field experience of thirty-six landscape horticulturists (see the section "Regional Committees") and provides guidance in the selection and care of landscape plants relative to their water needs.

WUCOLS IV provides an assessment of

irrigation water needs for over 3,500 taxa. Photo by Ellen Zagory.

Project Background

The WUCOLS project was initiated and funded by the Water Use Efficiency Office of the California Department of Water Resources (DWR). Work was directed by the University of California Cooperative Extension, San Francisco and San Mateo County office. The first edition of the guide was completed in 1992. A second edition was published in 1994, and a third edition in 1999. In each new edition, additional species were evaluated and included.

Current Update: The 4th Edition

The 4th edition represents a substantial expansion in the number of plant evaluations. Over 1,500



- Things you need to know
 - Distribution uniformity
 - Precipitation rate
 - Soil texture
 - Landscape and plant coefficients (K_L)
 - Climate (ET₀)



CIMIS

C alifornia I rrigation Management I nformation S ystem Collects weather info Estimates plant water use More than 120 stations

Water use reports are used with a crop or landscape coefficient to estimate site water use

http://wwwcimis.water.ca.gov/cimis/

Climate

• Water use models

Based on weather data Requires previous research Crop specific Easy to use

Climate

• Water use models

Reference ET (ET_0) is reported (CIMIS) Crop coefficient (K_c) is necessary Determine ET_{crop} (ET_c) to estimate crop water use so, $ET_c = ET_0 \times K_c$ **Example: citrus orchard** $K_{c} = 0.65$ If $ET_0 = 0.5''$, then crop water use is 0.325" $(0.325=0.5 \times 0.65)$

T	120	132*	121	120'
	I HERE		- 3-	
ORTE	SISK	10 10	моро	C TO
24	12 2	N. A.	7	The same

Reference EvapoTranspiration (ETo) Zones

STAL PLAINS HEAVY FOG BELT set ETo in California. Characterized by dense fog

7000 1

Sierra Nevada Mountain valleys east of Sacramento with some influence from the delta breeze in summ

NORTH COAST MOUNTAINS 12 EAST SIDE SACRAMENTO-SAN JOAQUIN W Low winter and high summer ETo with sligh lower ETo this zone 14

ivionti	niy Av	erage	e Rete	erence	e Eva	potrar	ispira	tion d	y E I O	Zone	e (incr	ies/m	ontn)
Zone	Jan	Feb	Mar	Apr	May	Jun	Jul	Aug	Sep	Oct	Nov	Dec	Total
- 1 -	0.93	1.40	2.48	3.30	4.03	4.50	4.65	4.03	3.30	2.48	1.20	0.62	32.9
2	1.24	1.68	3.10	3.90	4.65	5.10	4.96	4.65	3.90	2.79	1.80	1.24	39.0
3	1.86	2.24	3.72	4.80	5.27	5.70	5.58	5.27	4.20	3.41	2.40	1.86	46.3
4	1.86	2.24	3.41	4.50	5.27	5.70	5.89	5.58	4.50	3.41	2.40	1.86	46.6
5	0.93	1.68	2.79	4.20	5.58	6.30	6.51	5.89	4.50	3.10	1.50	0.93	43.9
6	1.86	2.24	3.41	4.80	5.58	6.30	6.51	6.20	4.80	3.72	2.40	1.86	49.7
7	0.62	1.40	2.48	3.90	5.27	6.30	7.44	6.51	4.80	2.79	1.20	0.62	43.3
8	1.24	1.68	3.41	4.80	6.20	6.90	7.44	6.51	5.10	3.41	1.80	0.93	49.4
9	2.17	2.80	4.03	5.10	5.89	6.60	7.44	6.82	5.70	4.03	2.70	1.86	55.1
10	0.93	1.68	3.10	4.50	5.89	7.20	8.06	7.13	5.10	3.10	1.50	0.93	49.1
11	1.55	2.24	3.10	4.50	5.89	7.20	8.06	7.44	5.70	3.72	2.10	1.55	53.1
12	1.24	1.96	3.41	5.10	6.82	7.80	8.06	7.13	5.40	3.72	1.80	0.93	53.4
13	1.24	1.96	3.10	4.80	6.51	7.80	8.99	7.75	5.70	3.72	1.80	0.93	54.3
14	1.55	2.24	3.72	5.10	6.82	7.80	8.68	7.75	5.70	4.03	2.10	1.55	57.0
15	1.24	2.24	3.72	5.70	7.44	8.10	8.68	7.75	5.70	4.03	2.10	1.24	57.9
16	1.55	2.52	4.03	5.70	7.75	8.70	9.30	8.37	6.30	4.34	2.40	1.55	62.5
17	1.86	2.80	4.65	6.00	8.06	9.00	9.92	8.68	6.60	4.34	2.70	1.86	66.5
18	2.48	3.36	5.27	6.90	8.68	9.60	9.61	8.68	6.90	4.96	3.00	2.17	71.6

ETo Zones

California

Variablity between stations within single zones is as high as 0.02 inches per day for zone 1 and during winter months in zone 13. The average standard deviation of the ETo between estimation sites within a zone for all months is about 0.01 inches per day for all 200 sites.



http://www.cimis.water.ca.gov/Content/pdf/CimisRefEvapZones.pdf

• So,

- We know how much to apply (1.2 in)
- Replaces ½ of field capacity

• Then,

- We need to estimate when that amount of water is used
- We know our plants
- We have info about the climate

- Landscape and plant coefficients (K_L)
 For this example, 0.4
- Climate (Water Use Rates)

Monthly Average Reference Evapotranspiration by ETo Zone (inches/month)													
Zone	Jan	Feb	Mar	Apr	May	Jun	Jul	Aug	Sep	Oct	Nov	Dec	Total
14	1.55	2.24	3.72	5.10	6.82	7.80	8.68	7.75	5.70	4.03	2.10	1.55	57.0

October = 4.03 in/month

 $-ET_{day} = 4.03$ in $\div 31$ days = 0.13 in/day

How fast is our landscape using water?
 - $ET_L = ET_{day} \times K_L$ - $ET_{day} = 0.13 \text{ in/day}$ - $K_L = 0.4$

ET_L = 0.13 x 0.4 = 0.07 in/day



October

 $ET_0 = 0.13$ × $K_L = 0.4$ = $ET_L = 0.07$ Irrig = 1.2

Day	Total ET ₁
1	0.07
2	0.14
3	0.21
4	0.28
5	0.35
6	0.42
7	0.49
8	0.56
9	0.63
10	0.70

October

 $ET_0 = 0.13$ $\times K_1 = 0.4$ = ET_L = 0.07

Irrig = 1.2

				1
Day	Total ET _I	Day	Total ET ₁	
1	0.07	11	0.77	
2	0.14	12	0.84	1.19
3	0.21	13	0.91	+ 0.07 (E
4	0.28	14	0.98	= 1.26
5	0.35	15	1.05	
6	0.42	16	1.12	
7	0.49	17	1.19	
8	0.56	18	1.26	\triangleright
9	0.63	19	0.32	
10	0.70	20	0.40	

October

 $ET_0 = 0.13$ × $K_L = 0.4$ = $ET_L = 0.07$

Irrig = 1.2

Day	Total ET	Day	Total ET ₁	
1	0.07	11	0.77	
2	0.14	12	0.84	
3	0.21	13	0.91	
4	0.28	14	0.98	
5	0.35	15	1.05	
6	0.42	16	1.12	
7	0.49	17	1.19	
8	0.56	18	0.06	>
9	0.63	19	0.13	
10	0.70	20	0.20	



October

 ET_0 = 0.13 ×K = 0.4 = ET_L = 0.07

Irrig = 1.2

Day	Total ET ₁	Day	Total ET	Day	Total ET
1	0.07	11	0.77	21	0.27
2	0.14	12	0.84	22	0.34
3	0.21	13	0.91	23	0.41
4	0.28	14	0.98	24	0.48
5	0.35	15	1.05	25	0.55
6	0.42	16	1.12	26	0.62
7	0.49	17	1.19	27	0.69
8	0.56	18	0.06	28	0.76
9	0.63	19	0.13	29	0.83
10	0.70	20	0.20	30	0.90

= 0.13
= 0.4
= 0.07
= 1.2

October	
Day	Total ET_{L}
1	0.07
2	0.14
3	0.21
4	0.28
5	0.35
6	0.42
7	0.49
8	0.56
9	0.63
10	0.70

- For more accuracy
 - Use actual instead of historical data
 - Obtain daily ET₀
 from CIMIS
 - Calculate & accumulate actual ET_L

- Determine when to irrigate
 - Irrigation application = 1.2 in
 - $ET_{L} = 0.07 in/day$
- Method 1
 - Accumulate ET_L daily
 - When accumulated total reaches 1.2 in
 - Irrigate!
- Method 2
 - 1.2 in ÷ 0.07 in/day = 17.1 days
 - Irrigate every 17 days

• Method 3

- ccuh.ucdavis.edu
 - "irrigation scheduling worksheet"
- Conduct catch can test
- Enter catch can volumes and other information
 - Depth to wet, designated days
- Calculates:
 - DU, PR
 - Run time (duration and cycles)
 - Annual irrigation calendar

Topics

- Why plants need water
- Irrigation management
 - Assessing system performance
 - Scheduling
 - Smart controllers

Smart Controllers

- What they do
 - "automatically" adjust irrigation to "plant water needs"
 - Information needed: See previous sections irrigation scheduling
 - Irrigation system specifics
 - Plant mix
 - Slope
 - Weather

Smart Controllers

- How they adjust
 - Not all controllers are "good"
- Programs are adjusted in two ways:
 - 1. Modify run times, fixed schedule
 - 2. Modify schedule, fixed run times

Topics

- Why plants need water
- Irrigation management
 - Assessing system performance
 - Scheduling
 - Smart controllers
- Maintaining plants
 - Turf
 - Trees and shrubs
 - Edibles

Turf



Turf



Trees What's the problem?

- Planted in or adjacent to turf
- Improper tree selection
- Poor irrigation management
- Shallow roots



A Common Sight in 2014









Recognize water stress

Incipient

- Color change to bluish or grayish green
- Temporary
 Flagging, wilting
- Permanent wilting
 - Desiccation, drying
 - Nonrecoverable



Secondary effects

- Susceptibility to:
 - Insects
 - e.g., Borers
 - ambrosia beetles
 - longhorned eucalyptus borers
 - Diseases
 - e.g., Root rots
 - Phytophthora
 and Oak root fungus
 - Armillaria



Tree roots

- Relationship to canopy
- May be deep
 - Depends on soil and irrigation history



Where to Irrigate

- Deep to 2 -3 feet
- Beneath the canopy
 - Beyond the drip line
 - Not at trunk
- Every 2-4 weeks or so



Mature Gingko Tree Considered Deep Rooted





Tree Ring Irrigation Contraption Loren Oki and Dave Fujino

- Input info for 1' spacing:
 - Canopy radius, soil type, no. of 100' drip lengths
- Calculates irrig. run time to wet soil to 36" deep
- http://ccuh.ucdavis.edu/
 - Search: CCUH TRIC
- ~\$100 for parts





- Low cost ~\$20
- Runtime depends on soil type
- http://ccuh.ucdavis.edu/
 Search: CCUH RSIC

Rotary System Irrigation Contraption Loren Oki and Dave Fujino





Tree roots

Recently planted trees

- Roots are mostly within the container soil ball
- Roots may be just entering the native soil
- Will take several years to fully establish



Topics

- Why plants need water
- Irrigation management
 - Assessing system performance
 - Scheduling
 - Smart controllers
- Maintaining plants
 - Turf
 - Trees and shrubs
 - Edibles

Edibles

- Use the same principles as for landscapes
 - Be aware that "production" is usually associated with higher water use
 - To maximize production, minimize water stress
 - Maintain soil moisture to avoid water stress
 - Productivity is related to photosynthesis
 - Photosynthesis is dependent on CO₂
 - CO₂ enters through stomates
 - Stomates close with water stress

Topics

- Why plants need water
- Irrigation management
 - Assessing system performance
 - Scheduling
 - Smart controllers
- Maintaining plants
 - Turf
 - Trees and shrubs
 - Edibles
- Fire Safe

Fire Safe

- ucanr.edu/sites/SAFELandscapes
- CalFire (fire.ca.gov)
- readyforwildfire.org





Topics

- Why plants need water
- Irrigation management
 - Assessing system performance
 - Scheduling
 - Smart controllers
- Maintaining plants
 - Turf
 - Trees and shrubs
 - Edibles
- Fire Safe

Thank you lroki@ucdavis.edu